


IBM 46XX

The digital scanner automatically detects the host interface type, but there is no default setting. Scan one of the barcodes below to select the appropriate port.



Non-IBM Scanner Emulation (Port 5B)




Hand-Held Scanner Emulation (Port 9B)



Table-Top Scanner Emulation (Port 17)

Keyboard Wedge

The digital scanner automatically detects the host interface type and uses the default setting. If the default (*) does not meet your requirements, scan the IBM PC/AT and IBM PC COMPATIBLE barcode below.



*IBM AT Notebook



IBM PC/AT & IBM PC Compatibles

Set Defaults



Return to Factory Defaults

Add a Tab Key

To add a Tab key after scanned data, scan the barcode below.



Add a Tab Key

Add an Enter Key (Carriage Return /Line Feed)

To add an Enter key after scanned data, scan the barcode below.



Add Enter Key

USB Caps Lock Override




USB-Override Caps Lock Key
(Enable)



*USB - Do Not Override Caps Lock Key
(Disable)

Scanning

Hands-Free
(Presentation)



Hand-Held

